Narrow Band Emergency Messaging System Installation and Setup Guide

The first thing to do is to install the NBEMS programs. You can find a link to them on the SHARP web site. First go to www.sacsharp.org and click the Member's Area link at the bottom of the first page. Then enter the SHARP member username and password. You'll then get the basic home screen for members. Click the NBEMS link on the menu to get to the NBEMS page.

To get to the NBEMS download page, go to http://www.w1hkj.com/download.html

After you click the link shown above, you'll get the web page shown below. Locate your operating system (Linux, Windows, OS X) and then go down the column and download the programs you need.

Downloa	d page: upd	ated 11 July 20	14					
	Linux Binary	Windows Setup	OS X dmg		Puppy Pet (1)	Source	Help	Release Info
fldigi / flarq	fldigi-3.21.83.bin	fldigi-3.21.83 setup	fldigi-3.21.83 i386 dmg	f	fldigi-3.21	fldigi-3.21.83	fldigi-Help	<u>Maint'</u>
			fldigi-3.21.83 ppc dm	Loca	ate your ope	erating syste	em at the top and	d
	README	Setup.exe SHA256 che	cksums	then	the files to	r the progra	ms (shown in	
		required for all fl a	oplications on Puppy O	red)	. The blue	circles show	the choices for	·
RigCat Xmls	xml archives			a co	omputer wit	h MS Wind	ows. Use the	
				appr	opriate file	s for your co	omputer's	
flamp:	flamp-2.1.02.bin	flamp-2.1.02 setup	flamp-2.1.02 i386 dm	oper	rating system	n.		
			flamp-2.1.02 ppc dmg					
flwrap:	flwrap-1.3.4.bin	flwrap-1.3.4 setup	flwrap-1.3.4 i386 dmg	<u>f</u>	flwrap	flwrap-1.3.4	flwrap-Help	Maint'
			flwrap-1.3.4 ppc dmg				flwrap Help PDF	
flmsg:	flmsg-2.0.4.bin	flmsg-2.0.4 setup	<u>flmsg-2.0.4 i386 dmg</u>	f	flmsg	<u>flmsg-2.0.4</u>	<u>flmsg-Help</u>	Maint'
			flmsg-2.0.4 ppc dmg				flmsg-Help-PDF	
flwkey:	flwkey-1.1.6.bin	flwkey-1.1.6 setup	flwkey-1.1.6 i386 dmg	f	flwkey	<u>flwkey-1.1.6</u>	flwkey-Help	<u>Maint'</u>
			flwkey-1.1.6 ppc dmg				flwkey Help PDF	
flrig:	flrig-1.3.16.bin	flrig-1.3.16 setup	<u>flrig-1.3.16 i386 dmg</u>	f	flrig	flrig-1.3.16	flrig-help	<u>Maint'</u>
			flrig-1.3.16 ppc dmg				flrig Help PDF	
fllog:	fllog-1.1.8.bin	fllog-1.1.8 setup	fllog-1.1.8 i386 dmg	f	fllog	<u>fllog-1.1.8</u>	fllog-help	<u>Maint'</u>
			fllog-1.1.8 ppc dmg				fllog Help PDF	
flnet	flnet-7.2.1 bin	flnet-7.2.1 setup	flnet-7.2.1 i386 dmg			flnet-7.2.1	flnet help	

Installing these programs on your computer is just like installing any other program you've downloaded for installation. Download and install the correct version of Fldigi / Flarq, Flwarp and Flmsg for your computer's operating system.

Once fldigi is installed, we need to set it up! First thing to do is configure the operator settings. Select "Configure" and then "Operator." <u>I suggest you use this technique to get into configuring anything in fldigi, because it's really the simplest way to get to the configuration settings.</u>



Configure your operator information. Fill in the boxes with your information. Don't know your "Locator" (aka Maidenhead Grid Square)? You can leave it blank for now or <u>find it here</u>. Fill in the boxes and <u>BE SURE TO CLICK "Save" when</u> you're done.

2	2th				St	Pr [Loc						
	I	Fldigi confi	iguration							- 6	×		
	Ope	rator UI	Waterfall	Modems	Rig Audio	ID Mi	sc Web						
		Station								_			
			Callsign:	NM3S]	Na	ame: Mike A]			
			QTH:	Sacrament	0]			
			Locator:	CM98gm									
			Antenna:	40 Meter L	оор)			
											Be sure	to click	the
										د	'Save"	button a	ifter you
										1	fill in th	ne inform	nation.
								Ľ		~			
		Restore	e defaults		_		Save		Close	2	<u> </u>		

Next, click MODEMS, then click MT-63 and UNCHECK the "Allow manual tuning" box. This avoids tuning errors on MT-63. As always, when you change a configuration page, click the "Save" button!



Next, configure the input. THIS IS CRITICAL SO BE CAREFUL!

To get started, first, if you are going to be using any kind of cable or hardware interface, CONNECT THE CABLES up to everything and turn it all on. This is necessary so the computer can "see" any device you are using. (Of course, you do NOT have to have any hardware interface between your radio and computer at all, but it is easier if you have one. I suggest you at least hook a patch cable between the radio's external speaker jack and the computer's line in or microphone jack, although, again, it is NOT absolutely required.)

Once you've got everything hooked up, click the <u>Audio</u> tab, and then click the <u>Devices</u> tab. We will be setting the devices to be used for "Capture" (which is the audio from the radio to the computer) and for "Playback" (which is the audio from the computer to the radio). Which set of choices below will you want to use? It depends on the hookup between your radio and computer. There are three different kinds of hookups covered here:

- 1) Rigblaster interface OR single patch cord between radio's external speaker jack to computer microphone or line in jack (you will hold the radio's mic by the computer's speaker for transmit).
- 2) No wires at all between computer and radio
- 3) SignaLink interface

The exact choices that will show up on YOUR computer for "Capture:" and "Playback:" may differ from those shown below. However, you should see options SIMILAR to those shown. You may need to experiment a little to find the option that works for you.

Also, please note that, whatever your setup, the PortAudio box MUST always be checked!

Option 1, Rigblaster OR <u>using a single wire between the radio and computer for the radio's audio</u>. The setup shown directly below should work for you. "Capture" should be <u>Line In</u> and "Playback" should be <u>Speakers.</u>



Option 2, not using any wires at all, you would use the setup shown below. Note that the exact language and setup of the drop down lists may vary depending on your computer and devices attached to it. But here for "Capture", we are selecting <u>Microphone</u> as shown below.

Devices Settings Right chappel Step 2, Cl	Audio TD Misc Web	Step 4, select "Microphone" for "Capture"
Captu Playba PulseAudio Step 3, make sure, PortAudio is checked	re: Microsoft Sound Mapper - Input Microphone (2- High Definition Windows DirectSound devices erver string: d!	Primary Sound Carfure Driver Microphone (2- High Definition Audio Device)]
Restore defaults	See below for	steps 5 and 6.

For PLAYBACK we select SPEAKERS. Below is how it looks after you're all done.

berator UI Waterfall	1odems Rig Audio ID Misc Web	
⊖oss	Device: Step 5, sel	ect "Speakers" for playback.
PortAudio	Capture: Microphone (2- High Definition Audio Device)	
○PulseAudio	Server string:	
□File I/O only	Step 6, click your change	k "Save" to save es.
Restore defaults	Save Close /	

Option 3, using a SignaLink device. You will want to select "Microphone (USB Audio CODEC)" for <u>Capture</u> and "Speakers (USB Audio CODEC)" for <u>Playback</u>.

Fldigi configuration Operator UI Waterfall Mo Devices Settings Right cha	Step 1, Click the "Audio" tab.
Ooss Step 2, C	ick the "Devices" tab. Device: Step 4, Set "Capture" to "Microphone (USB Audio CODEC)
PrortAudio Prostep 3, make su checked. Frie 1/0 omy	Playback: Speakers (USB Audio CODEC) Fre PortAudio is Step 5, Set "Playback" to "Speakers (USB Audio CODEC)" Step 5, Set "Playback" to "Speakers (USB Audio CODEC)"
Restore defaults	Save Close

Another reminder, regardless of which option you went with above, once you've completed the audio device setup, <u>be</u> <u>sure to click SAVE!</u>

Operator UI Wate	rfall Modems Rig Au	idio ID Misc Web		
Devices Settings	Right channel			
⊖oss		Device:		
	Capture	Microphone (USB Audio CODEC)	\$	
⊘PortAudio	Playback	Speakers (USB Audio CODEC)	\$	
	Serv	ver string:		
□File I/O only				Be sure to click the <u>Save</u> button after you finish th
				settings!

The next task is to set up the NBEMS system to work correctly with flmsg. This is a very cool feature that allows your computer to instantly display to you any message sent you by another ham using flmsg. We must tell fldigi where flmsg is installed on the computer. Once we do that, whenever you receive a message from another ham using flmsg, fldigi can open your browser and/or flmsg and display the message to you.

First click the "Misc" tab and then the NBEMS tab. Then click the "Locate flmsg" button.

Fldigi configuration Operator UI Waterfall Modems Rig Audio It Mise CPU NBEMS Pskmail Spotting Sweet Spot Text i/o NBEMS data file interface Step 2, click the CPU Reception of flmsg files CPU Open with flmsg	Step 3, just note on this example where MY flmsg installed. I accepted the defaults. If you also did that, your flmsg might be in the same place.
Imsg: C:\Program Files\flmsg-1.1.23\flmsg.exe 2.0 Imsg: Restore defaults	Locate fimsg Timeout (secs) Save Close

This is the screen that appears when I click "Locate flmsg". Yours may look different. Note the folder "flmsg…" in the left hand window. Once you find the flmsg folder, click on it. Then the right hand window will show something like what is shown below. You want to locate the program file flmsg.exe. Note that the "exe" may not appear on your computer, depending on your settings and operating system. What I would do here is click on flmsg.exe in the right-hand panel to show fldigi the exact location of the flmsg.exe file. Then click the Open button.



Now that we've located flmsg, we need to tell fldigi what to do when we receive a message. Always click "Enable." Then you can click either or both "Open with flmsg" and "Open in browser." This controls what fldigi will do when it receives a message from another ham using flmsg. It can open flmsg with the fields filled in and/or open your default browser and display the message as an html formatted document. Personally, I suggest you click both of them, because you can always close one of the windows if you don't want it.

Fldigi configuration							
Operator UI Waterfall Modems	Rig Audio ID Misc Web						
CPU NBEMS Pskmail Spotting NBEMS data file interface	Sweet Spot Text i/o DTMF WX Step 1: always click "Enable"						
⊡Enable	Open message fold Step 2: check either or both of these (I suggest both).						
Reception of flmsg files	✓ Open in browser						
flmsg: C:\Program Files\flm	g-1.1.23\flmsg.exe Locate flmsg						
2.0	Timeout (secs)						
	Step 3: As always, click "Save" to save your changes.						

Another thing you might want to configure is a button to type your name. This is optional, but I recommend it. Look at the buttons just above the waterfall display. You'll see some of them are brown. Point at the brown button most to the right, directly next to the blue T/R button.



Next, <u>right</u> click the button – be sure to use the RIGHT button on the mouse. You'll see a screen like the one below. Click on the left hand window (labeled "Macro Text"). Press the <ENTER> key to create a blank line. Then type your name, a

colon and ONE SPACE. Then type the word "Name" in the space that says "Macro Button Label." Then click the "Apply" button, then the "Close" button.



You've just created a macro! These can be very useful. The macro you made will create a blank line (not a bad way to start a message – it will separate your message from a previously received message on the recipient's screen). After it creates a blank line, it will type your name, a colon and then a blank space. This setup makes fldigi messages look a lot like D-RATS messages, which many of us are familiar with. We'll use this button later when we look at how to send a test message.

Now that we've created a macro in fldigi, it would be nice if it would STAY there. However, it will not unless we perform another step that forces fldigi to SAVE THE MACROS. To do this, click "File", then "Macros", then "Save" as shown below:

٢	fldigi - NM3S	1223700		
	File Op Mode	<u>C</u> onfigure <u>V</u> iew <u>L</u> ogbook	Help	
l	Folders	• 🗐 🕥 Freq 147.920		
l	Macros	• Open		
l	Text Capture	• 🖹 Save		
l	Audio			
1	Exit	x		
1				
l				
l				Saving macros
l				
l				
I				

That way, our new macro will show up the next time you open fldigi. (For those interested in advanced features, you can actually have multiple, different sets of macros and load whichever one you like. For example, you might have a set of macros for VHF/UHF and another set for HF, or whatever you like.)

Now, we've completed all the basic configuration stuff that we only have to do once. <u>We're almost ready to actually</u> <u>SEND A MESSGE!</u>

There is one last setting we want to adjust before we actually test transmission, and that is volume on both the radio and computer. On the radio, keep the volume high enough that you could hear it clearly with normal voice transmission but not super loud. We're talking 1/3 to 1/2 full volume generally. That will provide plenty of volume for fldigi to work with. Do

NOT crank the volume! As to the computer volume for the radio, start with the volume adjusted about ½ full. Mine is shown below. By the way, if you're using a SignaLink, you should start with all three knobs at about the 9:00 position.



Last thing before we transmit is to select the "op mode", usually just called "mode". This determines the type of encoding, or "language", if you prefer, that fldigi will use. For our "digital tone" net on the SHARP repeater, we'll mostly use the MT63 mode. It's very robust and especially good on FM. You'll note there are three "flavors" of this mode, 500, 1000 and 2000. Those are the bandwidth used in Hz. The larger the number, the more bandwidth used and the faster the data transmission. But there is, of course, a tradeoff, which is if band conditions are not good, 2k won't work. With poor band

conditions, we will have to use a narrower bandwidth. If the band is especially poor, we may need to use another mode, called Olivia. However, most of the time we will be using MT63-2000.

Now you should be ready to send a test message. Turn on your radio and set it to the appropriate frequency. For test messages, I suggest using a simplex frequency and low power. In fldigi, click the "Name" button you created before, then type your message. I typed "This is a test message". Then, click the FAR RIGHT blue button to send the message. This is the best "send" button to use because it will send the text in the bottom window and then stop.



Note what happens when we hit the transmit button. The first thing it does is to add some stuff. The "de" is digital (and CW) shorthand for "from", and it adds your call sign automatically, so all messages you send will have your call sign – cool! It then adds a "k" which more shorthand and essentially means "over". The "^r" won't transmit and just tells fldigi to switch back to receive mode instead of staying in transmit mode. If that wasn't there you'd have to stop transmission manually

1	flo	digi - NM3S								
	<u>F</u> ile	Op <u>M</u> ode	Configure	<u>V</u> iew L	ogbook <u>H</u> elp	1				
	En	ter Xcvr Fred	a 🛄 🚱	Freq	147.920	On	Off 2159 Ir	Out		
		146.	420 🏷	Call		Op		Az		
1	FM	◄	▼ 2	Qth			St Pr	Loc		
l										
l										
ll										
ll										
L										
	мти	רוד ב- יו	bie ie	> to	st mossaro					
	de	NM3s k		ate	at message	•				
	^ r[
		CO M	A	NS M	oso 🕨		KN II	SK II	Me/Oth	Brag

Below is a picture something like the way your screen will appear after the test transmission is sent, if everything went well. Anything you receive will also appear in the top window. (That's why we want to start each message with a <return> key because it will make sure our message appears on a new line on the recipient's screen.) By the way, if things go wonky and you want to STOP TRANSMISSION NOW, you can click the T/R button in the lower right corner. This button has a "red light" icon that appears when it is transmitting. Clicking it will toggle fldigi between transmit and receive mode. That means, if you click it, just click it ONCE. It may take a few seconds to stop transmitting, but it will.

🖬 fidigi - NM3S	
File Op Mode Configure View Logbook Help	
Enter Xxvr Freq	
FM Image: Control of the second sec	
I CQ M ANS M QSO M KN II SK II Me/Qth Brag Name T/R Tx M Rx II TX M I CQ M ANS M QSO M KN II SK II Me/Qth Brag Name 7/R Tx M Rx II TX M I CQ M ANS M QSO M KN II SK II Me/Qth Brag Name 7/R Tx M Rx II TX M I CQ M ANS M QSO M KN II SK II Me/Qth Brag Name 7/R Tx M Rx II TX M I CQ M ANS M QSO M KN II SK II Me/Qth Brag Name 7/R Tx M Rx II TX M I CQ M ANS M QSO M KN II SK II Me/Qth Brag Name 7/R Tx M Rx II TX M I CQ M ANS M QSO M ANS M RX II TX M I CQ M ANS M RX II TX M I I TX M I CQ M ANS M QSO M ANS M RX II TX M I I CQ M ANS M RX II TX M I I TX M I I CQ M ANS M RX II TX M I I I I I I I I I I I I I I I I I I	If you want transmiss STOP NOW, click th ONCE.
(MT63-2K Dout Audio error: Upanticipated host error	

ONE LAST IMPORTANT NOTE: before you click the "send" button, you MUST be sure the cursor is at the END of your message. This is where it normally will be if you just type the message, so it's usually no issue. However, if you make an

error and click back at the beginning or middle of your message to fix the problem, when you are finished typing, you MUST click at the end of the message so the "de", callsign and "k" will appear at the end of the message. If you don't, you'll get a mess on the screen like that shown below. And it will stop transmitting after the ^r, so it won't even send the whole message! Boy will I look dumb! To make this mess, I put the cursor right after the word "this" and clicked the transmit button. Go ahead and try it while you're testing, and you'll see what I mean. This is an easy problem to avoid once you're aware of it, just remember to always click at the END of the message after you do any corrections and BEFORE you hit the transmit button!

MIKE A: This de NM3S k ^r[is a test message.

Your NBEMS should now be set up and ready to use.